

MITSUBISHI

PROGRAMMABLE CONTROLLER

MELSEC-A

User's Manual

MELSECNET/MINI-S3 master module type AJ71PT32-S3/AJ71T32-S3 (Hardware)

INTRODUCTION

Thank you for choosing the Mitsubishi MELSEC-A Series of General Purpose Programmable Controllers. Please read this manual carefully so that the equipment is used to its optimum. A copy of this manual should be forwarded to the end user.

 **MITSUBISHI ELECTRIC**
IB (NA) 66564-A

The United States	Mitsubishi Electronics America, Inc. (Industrial Automation Division) 800 Biermann Court, Mt Prospect, IL 60056 Phone: (708)298-8223
Canada	Mitsubishi Electric Sales Canada, Inc. (Industrial Automation Division) 4299 14th Avenue, Markham Ontario L3R 0J2 Phone: (416)475-7728
United Kingdom	Mitsubishi Electric UK Ltd., (Industrial Sales Division) Travellers Lane, Hatfield, Herts AL10 8XB Phone: (0707)276100
Germany	Mitsubishi Electric Europe GmbH, (Industrial Automation Division) Gothaer Strasse 8, Postfach 1548, D-4030 Ratingen 1 Phone: (02102)4860
Taiwan	Setsuyo Enterprise Co., Ltd., 1106 11th Fl., Chung-Ling Bldg 363 Sec 2, Fu Hsing S Rd Taipei, Taiwan R.O.C. Phone: (02)732 0161
Hongkong (& China)	Ryoden International Ltd., (Industrial & Electrical Controls Division) 10/F Manulife Tower 169 Electric Rd North Point Hong Kong Phone: 8878870
Singapore (& Malaysia)	MELCO Sales Shingapore Pte. Ltd., (Industrial Division) 307 Alexandra Rd #05-01/02 Mitsubishi Electric Bldg Singapore 0315 Phone: 4732308
Thailand	F.A Tech Co Ltd. 1138/33 34 Rama 3 Rd., Yannawa, Bangkok 10120 Phone: (02)285-2861-4
Australia	Mitsubishi Electric Australia Pty Ltd (Industrial Controls Division) 348 Victoria Rd., Rydalmere, N S W 2116 Phone: (02)684 7200
Republic of South Africa	M S A Manufacturing (Pty) Ltd., (Factory Automation Division) P.O. Box 39733, Bramley, Johannesburg 2018 Phone: (011)444 8080

 **MITSUBISHI ELECTRIC CORPORATION**
HEAD OFFICE: MITSUBISHI DENKI BLDG MARUNOUCHI 2 TOKYO 100 TEL: 03-5638-2100 FAX: 03-5638-2101
NAGOYA WORKS: 1-14 YOKOYAMA 1-1 NAGOYA 466 JAPAN

When a bond from Japan, this manual does not require a application to the Ministry of International Trade and Industry for export transaction permission.

IB (NA) 66564-A (9/92) MEE Printed in Japan

Specifications subject to change without notice

1. GENERAL DESCRIPTION

1. GENERAL DESCRIPTION

This manual describes specifications and names of parts of the AJ71PT32-S3/AJ71T32-S3 MELSEC-NET/MINI-S3 master module (to be referred as AJ71PT32-S3/AJ71T32-S3) for use with MELSEC-NET/MINI-S3 data link system (to be referred to as MINI-S3 link in this manual)

(1) The table below lists the differences between the AJ71PT32-S3 and the AJ71T32-S3

Item	Difference	
	Optical Data Link	Twisted-Wire-Pair Data Link
AJ71PT32-S3	○	○
AJ71T32-S3	—	○

2. PERFORMANCE SPECIFICATIONS

2. PERFORMANCE SPECIFICATIONS

The performance specifications of the AJ71PT32-S3/AJ71T32-S3 are given in the table below. For general specifications, refer to the user's manuals of the PC CPUs for use with the MELSECNET/MINI-S3 data link system.

Item	Performance Specifications		Remarks
	Optical Data Link	Twisted-Pair Data Link	
For one master module	Max number of link stations	64	No limit to the number of master modules used
	Input (points)	512	Number of input output points = 8 per remote I/O station. Total number of input + output points = 512
	Output (points)	512	
I/O refresh time (msec)	3.2 to 18 *1 (when 64 stations are connected)		
Communication speed (BPS)	1.5M		
Optical transmission level (dB)	-14.4 to -11.6	—	
Optical receive level (dB)	-30 to -14	—	
Optical wave length (mm)	660 (Visible radiation)	—	
Max inter-station transmission distance (m/ft)	50 (35) *3	100 (50) *4	No limit overall distance
Number of I/O points occupied	I/O dedicated mode : 32 Extension mode : 48		Will be changed by the setting of mode switching jumper pins.
5V DC internal current consumption (A)	AJ71PT32-S3	0.35	
	AJ71T32-S3	0.3	
Weight (kg) (lb)	0.6 (1.32)		

*1 The I/O refresh time is determined by the number of remote modules connected in the system, their types, and the setting of the operation mode switch of the master module as indicated below.


R	Total number of remote stations
B	Number of AJ35PTF-128DT units connected
T	Number of remote terminal units connected

Mode Setting	Operation Mode Switch	I/O Refresh Time (msec)
I/O dedicated mode	Online automatic return (0)	I/O refresh time = 0.48 + (0.042xR) + (0.2xB)
	Online no-automatic return (1)	I/O refresh time = 0.46 + (0.053xR) + (0.2xB)
	Communication stop when error is detected (2)	I/O refresh time = 0.44 + (0.046xR) + (0.2xB)
Extension mode	Online automatic return (0)	I/O refresh time = 0.66 + (0.044xR) + (0.25xB) + (0.95xT)
	Online no-automatic return (1)	I/O refresh time = 0.54 + (0.058xR) + (0.25xB) + (0.95xT)
	Communication stop when error is detected (2)	I/O refresh time = 0.54 + (0.051xR) + (0.25xB) + (0.95xT)

- *2: The maximum inter-station transmission distance depends on the twisted-pair cable diameter as follows:
 0.2 mm² (0.00031 in²) to less than 0.5 mm² (0.00077 in²) 50 m (164 ft)
 0.5 mm² (0.00077 in²) or more 100 m (328 ft)
- *3: The inter-station transmission distance of the optical fiber cable is between 1 m (3.28 ft) and 50 m (164 ft). Normal communication cannot be guaranteed for distances less than 1 m. Assembling method of optical fiber cable differs depending on cable length: 1 m (3.28 ft) to less than 17 m (55.76 ft), or 17 m (55.76 ft) or more. For details, refer to the MELSECNET/MINI-S3 Master Module User's Manual.


3. NOMENCLATURE

3 NOMENCLATURE



No	Name	Description																													
1)	Operating status indicator LEDs RUN ○ ○ SD ○ ○ RD ○ ○ ERR [RD ○ ○ LOOP ○ ○ REM ○ ○ TEST ○ ○ MON [ERR ○ ○ X ○ ○ Y ○ ○ CPU [RD ○ ○ WR ○ ○	<table border="1"> <thead> <tr> <th>LED</th> <th>Definition</th> </tr> </thead> <tbody> <tr> <td>RUN</td> <td>ON indicates that the master module is normal. OFF indicates a hardware fault.</td> </tr> <tr> <td>SD</td> <td>Flicker indicates that data is being transmitted.</td> </tr> <tr> <td>RD</td> <td>Flicker indicates that data is being received.</td> </tr> <tr> <td rowspan="2">CPU</td> <td>RD</td> <td>ON indicates that the FROM instruction has been executed from the PC CPU.</td> </tr> <tr> <td>WR</td> <td>ON indicates that the TO instruction has been executed from the PC CPU.</td> </tr> <tr> <td rowspan="3">ERR</td> <td>RD</td> <td>ON indicates that a receive data error has occurred.</td> </tr> <tr> <td>LOOP</td> <td>ON indicates that a line error has occurred.</td> </tr> <tr> <td>REM</td> <td>ON indicates that a station is faulty.</td> </tr> <tr> <td>TEST</td> <td>ON indicates test mode.</td> </tr> <tr> <td rowspan="3">MON</td> <td>ERR</td> <td>ON indicates that the remote I/O station selected by the monitor station number setting switch is faulty.</td> </tr> <tr> <td>X</td> <td>ON indicates that the remote I/O station selected by the monitor station number setting switch is an input unit.</td> </tr> <tr> <td>Y</td> <td>ON indicates that the remote I/O station selected by the monitor station number setting switch is an output unit.</td> </tr> </tbody> </table>	LED	Definition	RUN	ON indicates that the master module is normal. OFF indicates a hardware fault.	SD	Flicker indicates that data is being transmitted.	RD	Flicker indicates that data is being received.	CPU	RD	ON indicates that the FROM instruction has been executed from the PC CPU.	WR	ON indicates that the TO instruction has been executed from the PC CPU.	ERR	RD	ON indicates that a receive data error has occurred.	LOOP	ON indicates that a line error has occurred.	REM	ON indicates that a station is faulty.	TEST	ON indicates test mode.	MON	ERR	ON indicates that the remote I/O station selected by the monitor station number setting switch is faulty.	X	ON indicates that the remote I/O station selected by the monitor station number setting switch is an input unit.	Y	ON indicates that the remote I/O station selected by the monitor station number setting switch is an output unit.
		LED	Definition																												
		RUN	ON indicates that the master module is normal. OFF indicates a hardware fault.																												
		SD	Flicker indicates that data is being transmitted.																												
		RD	Flicker indicates that data is being received.																												
		CPU	RD	ON indicates that the FROM instruction has been executed from the PC CPU.																											
			WR	ON indicates that the TO instruction has been executed from the PC CPU.																											
		ERR	RD	ON indicates that a receive data error has occurred.																											
			LOOP	ON indicates that a line error has occurred.																											
			REM	ON indicates that a station is faulty.																											
		TEST	ON indicates test mode.																												
		MON	ERR	ON indicates that the remote I/O station selected by the monitor station number setting switch is faulty.																											
			X	ON indicates that the remote I/O station selected by the monitor station number setting switch is an input unit.																											
			Y	ON indicates that the remote I/O station selected by the monitor station number setting switch is an output unit.																											

No	Name	Description																					
2)	Remote I/O station monitoring LEDs	Indicates the I/O status of the corresponding remote I/O station selected by the monitor station number setting switch. I/O status of partial refresh type remote I/O units and remote terminal units cannot be monitored. <table border="1"> <thead> <tr> <th>LED</th> <th>Definition</th> </tr> </thead> <tbody> <tr> <td rowspan="7">MON Y</td> <td>Y0</td> <td rowspan="7">Indicates the transmission data of the remote I/O station selected by the monitor station number setting switch.</td> </tr> <tr><td>Y1</td></tr> <tr><td>Y2</td></tr> <tr><td>Y3</td></tr> <tr><td>Y4</td></tr> <tr><td>Y5</td></tr> <tr><td>Y6</td></tr> <tr> <td rowspan="7">MON X</td> <td>X0</td> <td rowspan="7">Indicates the receive data of the remote station selected by the monitor station number setting switch.</td> </tr> <tr><td>X1</td></tr> <tr><td>X2</td></tr> <tr><td>X3</td></tr> <tr><td>X4</td></tr> <tr><td>X5</td></tr> <tr><td>X6</td></tr> <tr><td>X7</td></tr> </tbody> </table>	LED	Definition	MON Y	Y0	Indicates the transmission data of the remote I/O station selected by the monitor station number setting switch.	Y1	Y2	Y3	Y4	Y5	Y6	MON X	X0	Indicates the receive data of the remote station selected by the monitor station number setting switch.	X1	X2	X3	X4	X5	X6	X7
LED	Definition																						
MON Y	Y0	Indicates the transmission data of the remote I/O station selected by the monitor station number setting switch.																					
	Y1																						
	Y2																						
	Y3																						
	Y4																						
	Y5																						
	Y6																						
MON X	X0	Indicates the receive data of the remote station selected by the monitor station number setting switch.																					
	X1																						
	X2																						
	X3																						
	X4																						
	X5																						
	X6																						
X7																							
3)	Operation mode setting switch	Used to switch the link module mode. <table border="1"> <thead> <tr> <th>Switch Position</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ONLINE (A R)</td> <td>Online automatic return</td> </tr> <tr> <td>1</td> <td>ONLINE (U.R.)</td> <td>Online no automatic return</td> </tr> <tr> <td>2</td> <td>ONLINE (E S)</td> <td>Communication stop at online error detection</td> </tr> <tr> <td>3</td> <td>TEST1</td> <td>Line check mode</td> </tr> <tr> <td>4</td> <td>TEST1</td> <td>Luminous energy check mode *1</td> </tr> <tr> <td>5 to 9</td> <td>-----</td> <td>Not used</td> </tr> </tbody> </table> <p>Remark The TEST LED is lit when 5 is selected. The RUN and TEST LEDs are switched OFF when any of 5 to 9 is selected.</p>	Switch Position	Mode	Description	0	ONLINE (A R)	Online automatic return	1	ONLINE (U.R.)	Online no automatic return	2	ONLINE (E S)	Communication stop at online error detection	3	TEST1	Line check mode	4	TEST1	Luminous energy check mode *1	5 to 9	-----	Not used
Switch Position	Mode	Description																					
0	ONLINE (A R)	Online automatic return																					
1	ONLINE (U.R.)	Online no automatic return																					
2	ONLINE (E S)	Communication stop at online error detection																					
3	TEST1	Line check mode																					
4	TEST1	Luminous energy check mode *1																					
5 to 9	-----	Not used																					
4)	Monitor station number setting switch	Sets the remote I/O station number to be monitored on the corresponding batch refresh type remote I/O station monitoring LED. For details refer to MELSECNET/MINI-S3 Master Module User's Manual. <ul style="list-style-type: none"> Set a station number in the range of 01 to 64. X10: Left digit of a station number X1: Right digit of a station number 																					
5)	Installation socket for the initial data ROM	This socket is used to install the ROM containing the initial data when the master module is used in the extension mode. (The ROM need not be when the master module is used in the dedicated mode.) Initial data is written to the ROM using the SW[] MINIP type system floppy disk.																					
6)	Installation socket for the message	This socket is used to install the ROM containing message data used for display on the LCD of the operating box when the operating box is used in the MINI-S3 link. (The ROM need not be installed when the operating box is not used.) Message data is written to the ROM using the SW[] MINIP type system floppy disk.																					
7)	Jumper for the use mode switch	This jumper determines whether the master module operates in the extension mode or the I/O dedicated mode. Extension mode: Jumper is placed in the "48" position. I/O dedicated mode: Jumper is placed in the "32" position. <p>REMARKS</p> <ol style="list-style-type: none"> The jumper is set in the "32" position when shipped from the factory. "32" and "48" are the number of I/O points in the master module when set in the corresponding mode. 																					
8)	Connector for the optical fiber cable	This connector is used for an optical fiber cable when communication with remote units is conducted in an optical data link. <p>RD(IN): Connected to SD(OUT) of the previous station. SD(OUT): Connected to RD(IN) of the succeeding station.</p>																					

No	Name	Description
9)	Twisted-pair cable terminal block 	This connector is used for an twisted-pair cable when communication with remote units is conducted in a twisted-pair data link SDA : Connected to RDA of the succeeding station SDB : Connected to RDB of the succeeding station RDA : Connected to SDA of the previous station RDB : Connected to RDB of the previous station SG : Connected to SG of the succeeding and previous stations FG : Connection of shield of shield cable and grounding wire

*1 Cannot be used with AJ71T32-S3
However, if switch position "4" is selected, the TEST LED will come on; this does not indicate an error

4. WIRING

4. WIRING

4.1 Connection of Optical Fiber Cables

This section explains how to connect and disconnect optical fiber cables

(1) Connect the optical fiber cables as shown in Fig 4 1





Fig 4 1 Connection of Optical Fiber Cables

POINTS

- Remote number setting can be done independently of the order in which the data link cable is connected. For details, refer to the MELSECNET/MINI-S3 Master Module User's Manual
- Before connecting a fiber-optic cable to the module, always check the optical conductivity of the cable. Optical conductivity can be checked by an optical power tester. For details about optical power testers, consult your nearest Mitsubishi representative. Optical conductivity is checked as shown below

<p>[Connection] Connect both ends of the fiber-optic cable to the T and R connectors of the tester</p> 	<p>[Results] If the green lights of -27dBm or higher (LEDS on the front of the tester) go ON, the cable works properly If these lights do not go ON, check the following:</p> <ul style="list-style-type: none"> • Is the end face of the cable properly cut? • Is the end face clean? • Is the length of the cable 50 m or less (composite cable 35 m or less)?
--	--

4.2 Connection of Twisted-Pair Cables

Connect the twisted-pair shield cables as shown in Fig 4 2. The terminal arrangement of the remote I/O station is given in the MELSECNET/MINI-S3 Remote I/O User's Manual




Fig 4 2 Connection of Twisted-Pair Cables

REMARKS

- The twisted-pair shield cable terminal block uses M4 (0.16) screws. Use appropriate solderless terminals.
- Tightening torque is 78 to 137 N cm [8.93 to 14 kg cm (12.1 lb inch)]

POINT

When routing twisted-pair cables, pay cautions on the following points:

- Do not run or bundle the twisted-pair cable close to or with the main circuit, high-tension cables or load cables. Allow at least 100 mm (4 inch) clearance.
- When connecting the cables to the remote unit terminal block, run the twisted-pair cable as apart from the power supply or I/O cables as possible.
- Avoid using a part of the twisted-pair cables (1 pair of 3 pairs of twisted-pair cable) for the power supply cable if possible.

4.3 Connection of Units for both Optical Fiber and Twisted-Pair Data Links

Both the optical fiber and twisted-pair cables may be used in the same loop to connect any link unit for use as an optical fiber/twisted-pair data link model as shown in Fig 4 3

The POINT box in Section 4 2 gives details about precautions to take when using twisted-pair wire cables






Fig 4 3 Connection of Cables for Optical Fiber/Twisted-Pair Data Link Modes

POINTS

- Ground the shields of the receive or transmission terminals at one point.
- For the connection of an optical/twisted-pair data link model, use either optical or twisted-pair cable. Connection of the RD to a fiber-optic cable and the SD to a twisted-wire-pair cable, and vice versa, are possible. Connection using both of these cables is not allowed.
- Fit the attached protective caps to optical connectors when not in use; ambient light entering the optical connectors may cause a malfunction.

5. OUTSIDE DIMENSIONS

5. OUTSIDE DIMENSIONS



REVISIONS

A	
Feb., 1995	

IMPORTANT

- (1) Design the configuration of a system to provide an external protective or safety interlocking circuit for the CPs
- (2) The components on the printed circuit boards will be damaged by static electricity, so avoid handling them directly. If it is necessary to handle them, take the following precautions:
 - (a) Ground human body and work bench
 - (b) Do not touch the conductive areas of the printed circuit board and its electrical parts with and non-grounded tools etc.

Under no circumstances will Mitsubishi Electric be liable or responsible for any consequential damage that may arise as a result of the installation or use of this equipment.

All examples and diagrams shown in this manual are intended only as an aid to understanding the text, not to guarantee operation. Mitsubishi Electric will accept no responsibility for actual use of the product based on these illustrative examples.

Owing to the very great variety in possible applications of this equipment, you must satisfy yourself as to its suitability for your specific application.